



LED OPERATION INSTRUCTION


I. Keypad Schematic



II. Function Mode Press MODE Key will be switched to check time and date display mode



Time Display Mode



Date Display Mode


III. Main Function Introduction

1. Double key Operation: MODE and SET Key.
2. Two Modes: Time Display (Hour/Minute), Date Display (Month/Day)
3. 12 Hour System, Minute/Day, Spacing is 5, "1,2,3,4" is increasing adjustment, For example: Setting 17 minutes to "15" plus "2"
4. The LED light display will be turned off when there is no key operation within 5 seconds. Press any key to wake up.

IV. Function Setting Setting Order : Hour→Minute→Month→Day

1. Press any key to wake up the LED display mode, press the SET key for 3 seconds until the hour digits start to flash, indicating that has been entered the hour mode setting screen.
2. Press MODE key to adjust the selected number. (If PM, the PM on the left side of the watch will lighting), adjust the SET key to confirm
3. After Hour setting, press the SET key for one second, then minute is flashing. Press the MODE key to adjust. Press the SET key to confirm after adjustment.
4. After minute setting, press the SET key for one second. "DT" is lighting, indicating that it has entered the month adjustment mode setting screen. Press the MODE key to adjust. Press the SET key to confirm after adjustment
5. After month setting, press the SET key for one second, "DT" is still in the lighting state, the date is flashing, press the MODE key to adjust, press the SET key to confirm after adjustment

V. Key Operation



TIME MODE

Press MODE Key to Adjust


Press MODE Key to Adjust

Press MODE Key to Adjust


Press MODE Key to Adjust

LED机芯操作说明书


一. 按键示意图：



二. 产品功能模式：按MODE键可以切换查看时间和日期显示模式



时间显示模式



日期显示模式

三. 主要功能介绍：

1. 双键操作：MODE和SET键。
2. 2种模式：时间显示(小时/分钟)，日期显示(月份/日期)。
3. 12小时制，分钟/日期--间距是5，“1、2、3、4”则为增值调整，例如需设定17分钟，为“15”+“2”。
4. LED发光显示5秒内无按键操作会关闭LED显示，按任意键可唤醒。

四. 功能设定（设定顺序：小时→分钟→月→日）：

1. 按任意键唤醒LED显示模式，按住SET键3秒直至小时位开始闪动，表示现已进入小时模式设定画面。
2. 按MODE键，可以调整被选择到的数字（如果是下午，左侧的“PM”会闪动），调整完按SET键确定。
3. 小时设定后，按住SET键1秒，分钟在闪动，按MODE键进行调整，调整完按SET键确定。
4. 分钟设定后，按住SET键1秒，“DT”在闪动，表示已进入调月份模式设定画面，按MODE键进行调整，调整完按SET键确定。
5. 月份设定后，按住SET键1秒，“DT”仍处于闪亮状态，日期在闪动，按MODE键进行调整，调整完按SET键确定。

五. 按键操作：

